

Notes:

1. Follow recommendations in AGECE letter for project.
2. The geotechnical engineer should observe excavations prior to rockery construction.
3. AGECE should observe rockery construction.
4. Fill placed behind rocks should follow recommendation in letter.
5. Base row of rocks should be embedded at least 1 foot below ground surface.
6. Filter fabric should be placed between rocks and fill behind rocks.

