

## REINFORCING NOTES:

- SEE "GENERAL NOTES" FOR REINFORCING REQUIREMENTS.
- 2. SEE "TYPICAL MILD SLAB DETAILS" FOR ADDITIONAL INFORMATION.
- 3. SLAB REINFORCING SHALL BE PLACED IN THE FOLLOWING SEQUENCE: E-W BOTTOM BARS
  N-S BOTTOM BARS
  N-S TOP BARS
  E-W TOP BARS
- 4. FOR CONTINUOUS BOTTOM BARS, LAP BARS Lsb AS REQUIRED WITH LAPS AT 1/3 THE SLAB SPAN BETWEEN ADJACENT COLUMNS.
- 5. TWO OF THE CONTINUOUS BOTTOM BARS ARE TO BE PLACED EACH WAY THROUGH ALL COLUMNS WITH COLUMN VERTICAL REINFORCEMENT, UNLESS NOTED OTHERWISE.
- 6. BOTTOM BARS CALLED OUT ARE IN ADDITION TO CONTINUOUS BOTTOM MAT.
- 7. RX INDICATES STUD RAIL. STUD RAILS SHALL BE PLACED AT ALL COLUMNS. SEE "TYPICAL STUD RAIL REINFORCEMENT AT COLUMNS" DETAIL AND STUD RAIL SCHEDULE.
- 8. SEE "TYPICAL CONCRETE OPENINGS AND EMBEDMENTS" FOR ADDITIONAL REINFORCEMENT REQUIREMENTS. NOTIFY STRUCTURAL ENGINEER OF ANY OPENINGS NOT SHOWN ON THE STRUCTURAL DRAWINGS FOR WHICH THE TYPICAL DETAILS DO NOT APPLY. ADDITIONAL REINFORCEMENT MAY BE REQUIRED.
- 9. WHERE BAR LENGTH CANNOT BE ACHIEVED DUE TO SLAB EDGE, HOOK BAR.
- 10. WHERE NOTED AS "HOOKED", PROVIDE 90 OR 180 DEGREE HOOK AS SHOWN ON PLAN. NOTED BAR LENGTH IS LENGTH OF STRAIGHT PORTION OF BAR.

## TOWER A & B - LEVEL 1 LOBBY FRAMING PLAN 1/8" = 1'-0"

MT16 (11) #4x12'-0" @ 12" STAGGER 2'-0"

MT17 (11) #4x15'-0" @ 12" STAGGER 3'-0"

MT50 (6) #5x24'-2" @ 12" HOOK AT END

MILD TOP REINFORCEMENT SCHEDULE			MILD TOP REINFORCEMENT SCHEDULE			MILD TOP REINFORCEMENT SCHEDULE			MILD TOP REINFORCEMENT SCHEDULE			MILD BOTTOM REINFORCEMENT SCHEDULE		
MARK	REINFORCING	REMARKS	MARK	REINFORCING	REMARKS	MARK	REINFORCING	REMARKS	MARK	REINFORCING	REMARKS	MARK	REINFORCING	REMARKS
MT1	(13) #6x20'-0" @ 10"	STAGGER 6'-0"	MT18	(16) #8x20'-0" @ 8"	STAGGER 5'-0"	MT51	(11) #5x6'-8" @ 12"	HOOK AT END	MT80	#5 @ 12"	HOOK BOTH ENDS	MB1	#5x20'-0" @ 12"	STAGGER 2'-0"
MT2	(13) #7x20'-0" @ 10"	STAGGER 5'-0"	MT30	#5x20'-0" @ 12"	STAGGER 3'-0"	MT52	(11) #5x11'-2" @ 12"	HOOK AT END	MT81	#5x14'-2" @ 12"	HOOK AT END	MB2	#5x12'-0" @ 24"	STAGGER 2'-0"
MT3	(11) #7x20'-0" @ 12"	STAGGER 4'-0"	MT31	#5x20'-0" @ 10"	STAGGER 2'-0"	MT53	(7) #6x11'-0" @ 12"	HOOK AT END	MT82	#6x29'-0" @ 12"	HOOK AT END	MB4	(3) #5x12'-0" @ 14'	STAGGER 2'-0"
MT4	(11) #6x20'-0" @ 12"	STAGGER 4'-0"	MT32	#5x15'-0" @ 12"	STAGGER 2'-0"	MT54	(11) #5x14-2" @ 12"	HOOK AT END	MT83	#5x19'-2" @ 12"	HOOK AT END	MB5	#5x20'-0" @ 18"	STAGGER 2'-0"
MT5	(13) #5x15'-0" @ 10"	STAGGER 4'-0"	MT33	#5x12'-0" @ 12"	STAGGER 2'-0"	MT55	(16) #6x14'-0" @ 8"	HOOK AT END	MT84	#5x6'-8" @ 12"	HOOK AT END	MB6	#5x20'-0" @ 16"	STAGGER 2'-0"
MT6	(11) #6x15'-0" @ 12"	STAGGER 4'-0"	MT34	#5x20'-0" @ 12"	STAGGER 4'-0"	MT56	(6) #5x14'-2" @ 12"	HOOK AT END	MT85	#5x9'-2" @ 12"	HOOK AT END	MB7	(6) #5x15'-0" @ 16'	STAGGER 2'-0"
MT7	(15) #7x15'-0" @ 9"	STAGGER 3'-0"	MT35	#5x12'-0" @ 12"	STAGGER 1'-0"	MT57	(6) #6x9'-0" @ 12"	HOOK AT END	MT86	#5x11'-2" @ 12"	HOOK AT END	MB8	(11) #5x20'-0" @ 12	STAGGER 3'-0"
MT8	(6) #5x15'-0" @ 12"	STAGGER 3'-0"	MT36	#5x7'-6" @ 12"	STAGGER 0'-0"	MT58	(11) #6x14'-0" @ 12"	HOOK AT END	MT87	#6x11'-0" @ 12"	HOOK AT END	MB9	(3) #5x15'-0" @ 24'	STAGGER 2'-0"
MT9	(6) #7x15'-0" @ 12"	STAGGER 3'-0"	MT37	#4x12'-0" @ 12"	STAGGER 1'-0"	MT60	(16) #7x10'-10" @ 8"	HOOK AT END	MT88	#4x14'-4" @ 12"	HOOK AT END	MB15	(6) #5x30'-0" @ 24'	STAGGER 3'-0"
MT11	(11) #5x12'-0" @ 12"	STAGGER 2'-0"	MT38	#4x15'-0" @ 12"	STAGGER 1'-0"	MT61	(11) #5x14'-2" @ 12"	HOOK AT END	MT89	#4x6'-10" @ 12"	HOOK AT END	MB16	(11) #4x12'-0" @ 12	STAGGER 3'-0"
MT12	(16) #8x20'-0" @ 8"	STAGGER 5'-0"	MT39	#5x15'-0" @ 8"	STAGGER 2'-0"	MT62	(11) #4x11'-4" @ 12"	HOOK AT END	MT90	#4 @ 12"	HOOK BOTH ENDS	MB17	#6x5'-2" @ 24"	HOOK AT END
MT13	(21) #8x20'-0" @ 6"	STAGGER 5'-0"	MT40	#6x20'-0" @ 12"	STAGGER 4'-0"	MT63	(11) #4x14'-4" @ 12"	HOOK AT END	MT91	#4x9'-4" @ 12"	HOOK AT END,	-		
MT14	(21) #7x20'-0" @ 6"	STAGGER 5'-0"	MT42	#6x15'-0" @ 12"	STAGGER 2'-0"	MT64	(11) #4x19'-4" @ 12"	HOOK AT END	MT92	#6x14'-0" @ 12"	HOOK AT END			
MT15	(11) #5x15'-0" @ 12"	STAGGER 3'-0"	MT43	#7x15'-0" @ 6"	STAGGER 3'-0"	MT65	(11) #4x6'-10" @ 12"	HOOK AT END	MT93	#5x19'-2" @ 10"	HOOK AT END			

MT66 (16) #7x18'-10" @ 8" HOOK AT END

MT97 #7x10'-10" @ 12" HOOK AT END



. 0 **4** E

> 159 South Jackson St, Suit Seattle, Washington 9810<sup>2</sup> +1 206 624 5670 olsonkundig

Olson Kundig

MAGNUSSON
KLEMENCIC
ASSOCIATES

Structural + Civil Engineers
Seattle Chicago
www.mka.com
206 292 1200

principal architect

project manager

drawn by

checked by

job no. 20052

date 05/17/2024

revisions:

IFC SET 2 OF 3 05/17/2024

6 01/17/2025 ASI-006.1 04/08/2024 IFC SET 1 OF 3

11/18/2022 95% CD

no. date

AB CONNECTOR LEVEL 1 REINFORCING PLAN

S2.AB.11.R